




Ezy-Wash® Food Service Tapware

PRODUCT CODES:

- TF75WC-ESS
- TF76WC-ESS
- TF77WC-ESS



SPECIFICATIONS

- Lever action handles
- Quick action SBA's include brass jumper valve/ceramic components, with red or blue indicator buttons on 80mm lever action handles (optional yellow indicator buttons are also available)
- All units are finished in bright chrome plate
- Special units can be made to your specifications

IMPORTANT: All Ezy-Wash® Food Service taps are tested in accordance with AS/NZS 3718 and leave our premises in good working order.

TECHNICAL DATA

Inlet				1/2" BSP – Female
Outlet				Aerator
Headwork				Jumper Valve/Ceramic
Working Pressure Range (kPa)	Min		100	
	Max		500	
Working Temperature Range (°C)	Jumper Valve / Ceramic		Min	5
	Jumper Valve		Max	80
	Ceramic		Max	90
Nominal Flow Rate (LPM)				9
Finish				Chrome

NOTE: Galvin Specialised continually strive to improve their products. Specifications may change without notice.

TOOLS REQUIRED

- Spanner & Hex Key
- Thread tape


PRE-INSTALLATION

MOUNTING DETAILS


Hole Centres

- Hole centres must be at 150mm ±0.5mm (TF75 & TF76) and at 205mm ±0.5mm (TF77). This is critical to ensure easy installation
- Wall spuds must be 15BSP MI and protrude from the finished wall by no more than 15mm

Note: If a male thread connection on the tap is more suited. If so, please contact us on 1300 514 074.




TF75WC-ESS






INSTALLATION

IMPORTANT: Galvin Specialised products must be installed in accordance with these installation instructions and in accordance with AS/NZS 3500, the PCA and your local regulatory requirements. Water and/or electrical supply conditions must also comply to the applicable National and/or State standards. Failing to comply with these provisions shall void the product warranty and may affect the performance of the product.




1. Fit Wall Flange

- Remove the wall flanges from the supplied unit
- Fit the wall flange onto the wall spud with a 10mm hex key.
- We recommend using thread tape or equivalent to ensure the connection does not leak.



2. Mixing Unit Body

- Ensure the o-rings are fitted on to the spigot inside the loose nuts and then fit the tap unit onto the wall flanges.
- Screw up the loose nuts and tighten securely.



3. Testing

- Open the lever handles and ensure there is flow from both hot and cold outlets.
- Inspect the tap and check for any leaks.



TROUBLESHOOTING		
PROBLEM	CAUSE	RECTIFICATION
Taps are dripping water	Jumper valves are worn or damaged	Replace jumper valve
	Ceramic discs are worn or damaged	Remove and inspect SBA. Remove debris and/or replace SBA if damaged.
	Tap seat is damaged	Refurbish tap seat using a reseating tool.
Water is leaking from spindle	O-ring on jumper valve spindle is damaged or worn	Replace o-ring
Water is not flowing from tap	Water is turned off	Turn water on
	Aerator or flow regulator is blocked by debris	Remove aerator and/or flow regulator from tap and remove debris. Install an inline strainer.
Spindle is difficult to turn (jumper valve)	Build up of scale on spindle, spindle worn or o-ring has been damaged	Remove jumper valve, clean and regrease. Replace o-ring. Complete SBA may need to be replaced.
Handle is loose	Screw has come loose	Tighten handle screw
Flange does not screw down onto basin/sink surface	Tap bodies are set too far out	Re-position tap bodies and breach piece

SERVICE AND MAINTENANCE	
JUMPER VALVE TAPWARE	CERAMIC CARTRIDGE TAPWARE
<ol style="list-style-type: none"> Turn of the water supply and turn on the tap handle to drain water from the bodies. Remove the temperature indicator from the handle. Remove the handle from the tap. Unscrew the top assembly from the body. Check the o-ring on the spindle and the jumper valve for wear and damage. Replace if required. Clean the spindle and the body for debris. Place a new o-ring (if required) onto the spindle and re-grease with potable water approved grease. Re-assembly top assembly, ensure follow the product installation guidelines for the relevant product to re-assemble. 	<ol style="list-style-type: none"> Turn of the water supply and turn on the tap handle to drain water from the bodies. Remove the temperature indicator from the handle. Remove the handle from the tap. Unscrew the ceramic head part from the body. Check the o-ring on the ceramic head part for wear and damage. Replace if required. Clean the head part and the body of any debris. Replace the cartridge and hand tighten back into the body. Follow the product installation guidelines for the relevant product to re-assemble.

WARRANTY

The warranty set forth herein is given expressly and is the only warranty given by the Galvin Engineering Pty Ltd. With respect to the product, Galvin Engineering Pty Ltd makes no other warranties, express or implied. Galvin Engineering Pty. Ltd. hereby specifically disclaims all other warranties, express or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.

Galvin Engineering Pty Ltd products are covered under our manufacturer's warranty available for download from www.galvinengineering.com.au Galvin Engineering Pty Ltd expressly warrants that the product is free from operational defects in workmanship and materials for the warranty period as shown on the schedule in the manufacturer's warranty. During the warranty period, Galvin Engineering will replace or repair any defective products manufactured by Galvin Engineering without charge, so long as the terms of the Manufacturer's warranty are complied with.

The remedy described in the first paragraph of this warranty shall constitute the sole and exclusive remedy for breach of warranty, and Galvin Engineering Pty Ltd shall not be responsible for any incidental, special or consequential damages, including without limitation, lost profits or the cost of repairing or replacing other property which is damaged if this product does not work properly, other costs resulting from labour charges, delays, vandalism, negligence, fouling caused by foreign material, damage from adverse water conditions, chemical, electrical or any other circumstances over which Galvin Engineering has no control. This warranty shall be invalidated by any abuse, misuse, misapplication, improper installation or improper maintenance or alteration of the product.

